



AEROCCINO
BY NESPRESSO



EN	2-9
JP	10-21

AEROCCINO4



MORE RECIPES ON



<http://www.nespresso.com/ultimate-coffee-creations>



EN AEROCCINO4

CONTENT

SAFETY PRECAUTIONS	02
OVERVIEW	05
PREPARATION	06
CLEAN DIRECTLY AFTER EVERY USE.....	07
TROUBLESHOOTING.....	08
SPECIFICATIONS	08
WARRANTY	09

SAFETY PRECAUTIONS




These instructions are part of the appliance. Read all instructions and all safety instructions before operating the appliance. Save these instructions and pass them on to any subsequent owner.

Avoid risk of fatal electrical shock and fire

- Only plug the base into a suitable, earthed power socket. Make sure that the voltage of the power source is the same as that specified on the rating plate.
- The appliance is only to be used with the base provided.
- The use of accessory attachments not recommended by the appliance may result in fire, electric shock or injury to persons.
- To disconnect the appliance, stop any preparation, then remove plug from power socket.
- Disconnect by pulling out the plug and not pulling the cable itself, as this may damage the cable.

- Do not pull the cable over sharp edges, clamp it or allow it to hang down. Keep the cable away from heat and moisture.
- To avoid hazards, never place the appliance on or beside hot surfaces, for example, radiators, stove tops, gas burners or similar.
- Do not operate appliance with a damaged cord or plug or if it has malfunctioned, been dropped or is damaged in any manner.

A damaged cord, plug or appliance can cause electric shocks, burns and fire. Return appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.




Avoid possible harm when operating the appliance

- Do not touch hot surfaces. Use handles, protected surfaces or knobs.
- Always keep the lid closed during preparation.
- Scalding may occur if the lid is removed during the preparation.
- Extreme caution must be used when moving an appliance containing hot liquids.

Cleaning

- Unplug appliance when not in use for a long period and before cleaning. Allow to cool down before putting on or taking off parts, and before cleaning the appliance. Remove the appliance from the base before cleaning.



• Please make sure the bottom of the Aeroccino and area underneath the base is dry, especially the connector area, prior to use. Electricity and water together can cause a fatal electric shock.

- Never immerse the base neither the Aeroccino in water. Electricity and water together can cause a fatal electric shock.
- Do not use dishwasher for cleaning.
- Never leave the appliance unattended during operation. Keep it out of the reach of children. The appliance is only for use by persons who have sufficient experience and knowledge and are physically, sensory, and mentally able to operate the machine safely in accordance with these instructions.

- This appliance is intended to be used in households and similar applications only such as: staff kitchen areas in shops, offices and other working environments, farm houses.
- This appliance can be used by children 8 years old and older, as well as persons with reduced physical, sensory, mental capabilities or lack of experience, only if they have been given supervision and instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children under the age of 8 years old.
- Do not use outdoors.
- Do not use the appliance for anything other than its intended use.
- The appliance is intended to prepare beverages according to these instructions. No liability is accepted for other purposes, faulty operation or non-professional repairs. Guaranteed services are also excluded in such cases.

- Do not open the appliance. Hazardous voltage inside.



Disposal

Your appliance contains materials which can be recovered or recycled. Separation of the remaining waste products into different types facilitates the recycling of raw materials. You can obtain information on disposal from your local authority.

SAVE THESE INSTRUCTIONS

OVERVIEW



- 1 Lid
- 2 Seal
- 3 Whisk for all preparations
- 4 Jug or Aeroccino
- 5 Bottom connector
- 6 Base connector



- 7 Cold macchiato (Cold and soft milk foam)
- 8 Hot milk
- 9 Cappuccino (Warm and airy milk foam)
- 10 Latte macchiato (Warm and dense milk foam)

PREPARATION

⚠ WARNING: Risk of electrical shock and fire! Make sure the under side of the milk frother and area underneath the base is dry.

TIPS: For optimal milk froth, use cold semi skimmed milk at refrigerated temperature (about 4-6 °C). To guarantee hygiene conditions, use heat treated milk (pasteurized), refrigerated & freshly opened only. Milk which has been frozen will not froth. To ensure hygienic conditions and proper maintenance of the equipment, it is highly recommended to not use special enriched milks, powdered reconstituted milks nor flavoured milks.

⚠ CAUTION: Syrup, sugar, chocolate powder or any other additives should not be added directly in the jug. This may damage the coating during the preparation.

⚠ CAUTION: Make sure the frothing spring is not removed from the whisk. Risk of burning the coating.



1. Clean before the first use and after each use according to the cleaning instructions. Place the whisk in the jug.

4. Choose your milk preparation by pressing the dedicated button to start. Button pressed blinks during preparation and become steady on when the preparation is ready.



2. Fill milk frother up to one of the two «Max» level indicators: Lowest «Max foam» level indicator (120 ml) is for milk froth preparations. Highest «Max milk» level indicator (240 ml) is for hot milk preparations.

5. Pour the milk preparation in the cup. Use only a non-metal spoon to collect the foam in the jug. For hot and cold milk froth, preparation takes approx. 80 sec. For hot milk, preparation takes approx. 150 sec. Preparation can be stopped at any time by pressing the button or removing the Aeroccino from the base.



3. Put the lid on the Aeroccino. Make sure the connector is dry before you plug the Aeroccino to the base. The 4 buttons are steady on.

6. Aeroccino turns off automatically after 9 minutes of non-use. Press any of the 4 buttons to switch ON the Aeroccino.

NOTE: The milk froth volume depends on the kind of milk that is used and its temperature.

CLEAN DIRECTLY AFTER EVERY USE

⚠ CAUTION: Ensure the jug is cold before removing it from the base. Or, if removing with care, rinse with cold water immediately to cool down the jug and avoid burning risks.

⚠ CAUTION: In case the base needs to be cleaned unplug it first and use only a damp cloth. Make sure the connector is dry before operation. Do not immerse the base in water neither put in the dishwasher.

⚠ CAUTION: Do not use dishwasher for cleaning.

1



1. Remove the jug from the base.

2



2. Remove seal from lid.

3



3. Remove the whisk, and the spring from the whisk.

4



4. **Hand washing:** wash inner jug, seal, lid, whisk and spring with detergent and rinse with warm/hot water. Do not use abrasive material that might damage the surface of the equipment. Don't immerse in water.

5



5. Dry all Aeroccino parts with a fresh and clean towel, cloth or paper and reassemble all parts.

⚠ CAUTION: Do not immerse neither the jug nor the base in the water.

⚠ CAUTION: If the bottom part of the jug is wet, dry it before putting it back in contact with the base connector.

Aeroccino does not start.	<p>→ Be sure to position the jug correctly on the base and the whisk is attached correctly in the jug. The Aeroccino will start only if the connectors are dried.</p>
Quality milk froth not up to standard or milk burnt.	<p>→ For optimal milk froth, use cold milk or semi skimmed milk at refrigerated temperature (about 4–6° C). To guarantee hygiene conditions, use heat treated milk (pasteurized), refrigerated & freshly opened only. Milk which has been frozen will not froth. Syrup, sugar, chocolate powder or any other additives should not be added directly in the jug. This may damage the coating during the preparation.</p> <p>→ Be sure the jug and the whisk are clean.</p> <p>→ It is highly recommended to not use special enriched milks, powdered reconstituted milks nor flavoured milks.</p>
Fast red lights blinking on the 4 buttons (Aeroccino error).	<p>→ a) The appliance is too hot: clean the jug under cool water. Be sure the whisk is attached correctly in the jug.</p> <p>→ b) Not enough milk: fill milk frother up to one of the two «max» level. All the 4 buttons blink rapidly (3 red and 1 blue).</p> <p>→ c) Clean Aeroccino and check that there is no water on the base.</p> <p>→ d) If no change, then please call the <i>Nespresso Club</i>.</p>
Milk overflows.	<p>→ Check the corresponding indicator level.</p>

AEROCCINO4

4192



JP: 100 V, 50-60 Hz, 450 W

Nespresso warrants this product against defects in materials and workmanship for a period of one year from the date of purchase. During this period, *Nespresso* will either repair or replace, at its discretion, any defective product at no charge to the owner. Replacement products or repaired parts will be guaranteed for only the unexpired portion of the original warranty or six months, whichever is greater.

This limited warranty does not apply to any defect resulting from accident, misuse, improper maintenance, or normal wear and tear. Except to the extent allowed by applicable law, the terms of this limited warranty do not exclude, restrict or modify, and are in addition to, the mandatory statutory rights applicable to the sale of the product to you. If you believe your product is defective, contact *Nespresso* for instructions on where to send or take it for repair.

Please visit our website at www.nespresso.com to discover more about *Nespresso*.

取扱説明書



ご使用前に、必ず本書をお読みいただき、正しくお使いください。
お読みになったあとは、いつでも見られるところに必ず保管してください。

本製品を譲渡する場合は、本書21ページに購入日をご記入の上、本書を次の使用者にお渡しください。

もくじ

はじめに・安全上のご注意.....	10-14
各部のなまえ.....	15
使いかた.....	16
使用後のお手入れ.....	17
故障かな?と思ったら.....	18
仕様・廃棄について.....	19
保証について・ネスプレッソクラブ.....	20
保証書.....	21

はじめに・安全上のご注意

● 使用目的

- ・本製品は、本書に従って飲料を作るためのものです。その他の目的では使用しないでください。
- ・本製品は家庭あるいは家庭に類似した環境（小規模なオフィスおよび休憩室など）で使用するために設計、製造されています。屋外や業務用として使用しないでください。
- ・本製品は、日本国内用に設計されています。電圧や電源周波数の異なる海外では使用できません。
- ・本書に記載されていない使用方法によって生じた損害について当社は責任を負いません。

● 使用者について

取り扱いに不慣れな方や子供など、本書に従って取り扱うことができない方が使用する場合は、必ず安全面で責任を持てる方が介助してください。

● 安全上のご注意

ご使用前に、必ずこの「安全上のご注意」を最後までお読みください。ここに示した注意事項は、本製品を安全に正しくお使いいただき、ご自身や他の人々への危害や、財産への損害を未然に防止するためのものです。注意事項を「警告」と「注意」に区別して明示していますので、お使いの際には、必ずお守りください

安全上のご注意(つづき)



警告

この表示に従わずに、誤った扱いをすると、人が死亡または重傷を負う可能性が想定される内容を示しています。



注意

この表示に従わずに、誤った扱いをすると、人が軽傷を負う可能性がある内容、または物的損害の発生が想定される内容を示しています。

絵表示の例

次の記号は、注意（警告を含む）を促す内容があることをお知らせするものです。



一般的注意



感電注意

次の記号は、禁止の行為であることをお知らせするものです。



禁止



分解禁止



風呂場、シャワー室などでの使用禁止




水ぬれ禁止



ぬれ手禁止


次の記号は、行為を強制したり指示することをお知らせするものです。



一般的指示



電源プラグを抜く




アース線を確実に接続する

● 取扱上の注意事項



警告



取り扱いに不慣れな方や子供など、本書に従って取り扱うことができない方が使用する場合は、必ず安全面で責任を持てる方が介助する誤使用による感電、火災、やけどやその他の思わぬ事故を引き起こすおそれがあります。



子供に遊ばせない

感電、火災、やけど、けがのおそれがあります。



子供に電源コードを触らせない


感電や首に巻きつけて窒息するなど事故を引き起こすおそれがあります。





子供の手が届くところで使用しない

感電、やけど、けがをするおそれがあります。


安全上のご注意(つづき)


 本体や電源ベース、電源コード、電源プラグに水をかけたり、水に浸けたりしない
故障、感電、発火の原因になります。


 分解、修理、改造を行わない
修理が必要なときは、ネスプレッソクラブ（20 ページ）に連絡してください。


 本書に記載されていない清掃や点検などを行わない
けがや故障の原因になります。

⚠ 注意

 長期間使用しない場合は電源プラグを抜く
感電、火災の原因になります。

 他製品の部品や付属品と組み合わせて使用しない
けがや故障の原因になります。


 以下の環境に保管しない
守らない場合、故障の原因になります。
・暖房装置などの熱源の近く
・温度変化の激しい場所
・直射日光のあたる場所
・湿気の多い場所
・屋外やほこりの多い場所


 輸送するときは、以下のことを必ず守る
守らない場合、故障の原因になります。
・本体を乾燥させる
・購入時の箱に、付属の緩衝材で保護して入れる


● 設置場所の注意事項

⚠ 警告


 屋外や車、船舶、航空機などに設置しない
故障、感電、発火の原因になります。


 直射日光が当たる場所に設置しない
故障、発火の原因になります。

 暖房装置、コンロ、オーブン、ガスバーナー、その他の熱源の近くに設置しない
変形、故障、発火の原因になります。


 水しぶきがかかる場所に設置しない
故障、感電、発火の原因になります。


⚠ 注意

 水・牛乳などにぬれても問題のない場所に設置する
テーブルや台などを傷め、変色、変形の原因になります。

 壁や家具の近くには設置しない
蒸気や熱で、壁や家具を傷め、変色、変形の原因になります。


安全上のご注意(つづき)

 熱に弱い家具や敷物の上、不安定なところや抽出時の振動に弱いところには設置しない
テーブル、敷物を傷める原因になります。


 テーブルや台などからはみ出した状態で設置しない
落下して破損、やけど、けがのおそれがあります。


● 電源コード、コンセントの注意事項


⚠ 警告


 アース線を確実に接続する
火災・感電の原因になります。


 定格 15A 以上、交流 100V のコンセントを単独で使用する
他の機器と併用すると、発火するおそれがあります。


 延長コード、テーブルタップ、コーナータップなどを使用しない
異常発熱し、発火するおそれがあります。


 電源コードは本体の設置が終わってからコンセントに差し込む
やけど、けがの原因になります。


 電源プラグやコンセントに付いているほこりやごみは、定期的に清掃する
電源プラグを抜いて、乾いた布で拭き取ってください。放置すると火災の原因になります。

 電源プラグや電源コードを破損するようなことはしない
感電、火災の原因になります。
・傷つけたり、加工したりしない
・本製品の熱くなる部分やその他の熱器具に近づけたりしない
・無理に曲げたり、ねじったり、束ねたりしない
・はざんだり、重いものを載せたり、とがった場所に近づけたりしない
電源プラグや電源コードが破損したときは、ネスプレッソクラブ（20 ページ）に修理をご相談ください。

 電源プラグは壁面のコンセントの奥までしっかりと差し込む
感電、火災の原因になります。

 電源プラグや電源コードが破損した場合や、コンセントの差し込みがゆるい場合は使用しない
感電、火災の原因になります。
電源プラグや電源コードに破損を見つけたら、ネスプレッソクラブ（20 ページ）に修理をご相談ください。

 ぬれた手で電源プラグを抜き差ししない
感電のおそれがあります。

 電源プラグを抜くときは、電源コードを持たず、必ず電源プラグを持って抜く
電源コードが損傷し、感電、発火のおそれがあります。

安全上のご注意(つづき)

● 使用上の注意事項

⚠ 警告

- ⊘ 破損や故障した状態では使用しない
感電、火災のおそれがあります。
- ⊘ 異常発熱、異音、発煙などの異常を感じたら、速やかに電源プラグを抜く
感電、火災、やけど、けがの原因になります。
- ⊘ 熱くなっている本体表面に触れない
やけど、けがのおそれがあります。ハンドル(取っ手)をもってください。
- ⊘ 牛乳の調整中はフタをつけて、はずさないでください
やけど、けがのおそれがあります。
- ⊘ 温めた牛乳をいれたまま移動する場合には最大限注意してください
やけど、けがのおそれがあります。
- ⊘ 動作中は目を離さない
予期しない事故によるやけど、けがのおそれがあります。

⚠ 注意

- ⊘ 水・牛乳以外の液体をいれないでください
故障のおそれがあります。
- ! 牛乳は新鮮かつ冷えた状態のものを使用してください

● お手入れについての注意事項

⚠ 警告

- ⊘ エアロチーノ本体と電源ベースを水に浸さないでください
感電、火災、やけど、けがのおそれがあります。
- ⊘ エアロチーノ本体と電源ベースのお手入れに食器洗浄機はご使用になれません
感電、火災、やけど、けがのおそれがあります。

⚠ 注意

- ⊘ 清掃、点検の前には必ず電源プラグを抜く
感電、やけどのおそれがあります。
- ! 使用後はすぐに洗浄し、清潔な状態を保ってください
使用後のお手入れを行わないと、残った牛乳が腐ったり、汚れが取れにくくなったり、故障の原因となるおそれがあります。

各部のなまえ



- 1 フタ
 - 2 フタ用パッキン
 - 3 泡立てスプリング(プラスチックリング+スプリング)
 - 4 エアロチーノ本体/取っ手
 - 5 エアロチーノ本体底面接続部
 - 6 電源ベース接続部/電源ベース
 - 7 コールド・フォームミルクボタン(加熱をせずに、泡立てたい場合。)(所要時間:約80秒)
 - 8 ホットミルクボタン(泡立てなし。加熱する場合。)(所要時間:約150秒)
 - 9 カプチーノボタン(泡の量は少なめで少し粗い。加熱する場合。)(所要時間:約80秒)
 - 10 ラテ・マッキャート(泡の量は多めできめ細かい。加熱する場合。)(所要時間:約80秒)
- ヒント** 各ボタンの所要時間は、使用する牛乳の温度によって変わります。
(例:牛乳の温度が高い場合は、所要時間が短くなります。)

使いかた ヒント 上質な泡立ちのミルクをご準備いただくために：冷たい(4-6℃)新鮮な成分無調整の牛乳または同様の低脂肪乳をご使用ください。一度、凍結した牛乳は泡立ちがよくありません。



警告: エアロチーノ本体底面接続部および電源ベース接続部がぬれていないことを必ず確認してください。(感電のおそれ)


警告: アース線を確実に接続する



注意: エアロチーノ本体に水と牛乳以外の飲み物(シロップ、砂糖、チョコレートパウダーやその他の調味料)を入れない。(故障の原因)

注意: 泡立てスプリングがエアロチーノ本体の底の突起部分に正しく装着されていることを確認してください。(エアロチーノ本体の内部コーティングを傷つける原因)

注意: 清潔な状態かつ適切なお手入れを行っているエアロチーノをご使用ください。高脂肪乳、粉状のミルク、乳飲料のご使用はお勧めしません。



1. 初めてお使いになる前に、固くしぼった清潔なぬれた布できれいに拭いてください。ご使用後は必ず、使用後のお手入れを参照してお手入れを行ってください。そして、泡立てスプリングをエアロチーノ本体の底の突起部分へ正しく装着してください。

2. 牛乳を下記いずれかのmaxラインまで注いでください。下の「MAX FOAM」ライン(120ml)はミルクを泡立てる場合のMAXラインです。上の「MAX MILK」ライン(240ml)はミルクを泡立てないホットミルクを作る場合のMAXラインです。

3. エアロチーノ本体にフタを取り付けてください。電源ベースのプラグを壁のコンセントに差し込みます。4つのボタンが点灯します。エアロチーノ本体を電源ベースに設置してください。

4. お好みのボタンを押してください。各ボタンの詳細は、P.15「各部のなまえ」をご参照ください。動作中は、押したボタンが点滅します。終了すると点滅が点灯に変わります。

5. ミルクをカップに注いでください。残ったミルクの泡は、非金属性のスプーンを使用してかき集めてください。動作中にいずれかのボタンを押すと、止まります。また、エアロチーノ本体を電源ベースから取りはずしても止まります。

6. 9分間使用しないと自動的に電源が切れ、ボタンが消灯します。エアロチーノの電源を入れるには、4つのボタンのいずれかを押します。

使用後のお手入れ



警告: エアロチーノ本体を電源ベースからはずす際には、エアロチーノ本体が十分に冷えていることを確認してください。本体が熱い場合は、取っ手を持って冷たい水で洗って、やけどをしないように注意してください。



警告: 電源ベースが汚れてしまった場合には、まず電源プラグを抜き、乾いた布で汚れをふき取ってください。ご使用前には電源ベース接続部が乾いていることをご確認ください。電源ベースは水などでぬらさないようにしてください。

警告: エアロチーノ本体と電源ベースを水に浸さないでください。

警告: エアロチーノ本体底面接続部がぬれていた場合には電源ベースにセットする前によく乾かしてください。

注意: エアロチーノ本体と電源ベースのお手入れに食器洗浄機はご使用になれません。

注意: お手入れには固い材質のものは使用しないでください。エアロチーノ本体の内側表面を傷つける恐れがあります。

1



2



3



4



5



1. エアロチーノ本体を電源ベースからはずす
2. フタからフタ用パッキンをはずす
3. 泡立てスプリングをはずし、プラスチックリングとスプリングに分解する。

4. エアロチーノ本体の内側、フタ用パッキン、フタ、プラスチックリング、スプリングを台所用洗剤で洗い、ぬるま湯でよくすすいでください。

5. すべての部品を清潔なタオルもしくは紙タオルで水をふき取り、乾燥させてから組み立ててください。

お手入れの洗剤と道具

- 使用できるもの
 - ・ 台所用洗剤
 - ・ やわらかい布
- × 使用できないもの
 - ・ 樹脂部分が劣化・変質し、変色や傷、ひび割れ、故障の原因となります。
 - ・ 酸性・アルカリ性、漂白剤
 - ・ アルコールなどの有機溶剤
 - ・ クレンザーなどの研磨剤
 - ・ 化学ぞうきん

故障かな?と思ったら

エアロチーノが動作しない。	<p>→ エアロチーノ本体が電源ベースに正しくセットされているかご確認ください。</p> <p>→ 泡立てスプリングがエアロチーノ本体に正しくセットされているかご確認ください。</p> <p>→ エアロチーノは接続部分がぬれていない状態でのみ、動作します。症状が改善されない場合は、ネスプレッソクラブまでご連絡ください。連絡先は、P.20に記載しています。</p>
ミルクの泡の質がよくない。	<p>→ 冷たい (4-6℃) 新鮮な成分無調整の牛乳または同様の低脂肪乳をご使用ください。一度、凍結した牛乳は泡立ちがよくありません。エアロチーノ本体に水と牛乳以外の飲み物 (シロップ、砂糖、チョコレートパウダーやその他の調味料) を入れないでください。(故障の原因)</p> <p>→ エアロチーノ本体を清潔な状態にして、ご使用ください。泡立てスプリングの内側に牛乳成分が残っていて、回転を妨げている場合があります。泡立てリングを洗浄してください。</p> <p>→ 高脂肪乳、粉状のミルク、乳飲料のご使用はお勧めしません。</p>
3つ赤いボタンが早く点滅する。	<p>→ エアロチーノ本体が過熱状態です。冷たい水で、エアロチーノ内部を冷やしてください。泡立てスプリングがエアロチーノ本体に正しくセットされていることを確認してください。</p>
4つのボタンが早く点滅する。	<p>→ エアロチーノに入れた牛乳の量が十分でない可能性があります。MAXラインまで牛乳を入れてください。P.16手順2をご参照ください。</p> <p>→ 泡立てスプリングが正しくセットされているか確認する。</p>
ミルクがエアロチーノから溢れる。	<p>→ 適切な量の牛乳を注いでください。P.16手順2をご参照ください。</p> <p>→ 牛乳は、種類や季節によって乳成分が変動します。ご使用の牛乳より脂肪の少ないものに変えてみてください。</p>

仕様

家庭用

品名	ネスプレッソ牛乳沸かし器
機種名	エアロチーノ 4
品番	4192
定格電圧	100V
定格周波数	50/60Hz
定格消費電力	450W
重量(約)	1.1kg (本体、ベース、付属品含む)
大きさ(約)	本体 (取っ手を含む): 幅15.5×高さ17 (cm) 電源ベース: 直径15×高さ5.5 (cm)
ミルク容量(約)	泡立て用: 最大120ml 加熱用: 最大240ml

- 特定地域 (高地、厳寒地など) では、所定の性能が確保できないことがあります。
- この製品は、日本国内用に設計されています。電源電圧や電源周波数の異なる海外では使用できません。
- ネスプレッソは信頼性や性能の向上、法令の変更などを理由として、このモデルまたは将来の製品の改良、仕様変更を予告無く行うことがあります。
- 故障の際、または付属品の紛失・破損の際は、ネスプレッソクラブにご連絡ください。連絡先は、P.20に記載されています。

廃棄について

● ネスプレッソ牛乳沸かし器の廃棄について

この電気製品は、リサイクル可能な部分を含んでいます。廃棄される際には、適切な処理を受けるためにも、お住まいの地方自治体にお問い合わせください。

保証について



日本国内での保証条件については、P.21の保証書をご参照ください
Please refer to the warranty card on page 21.

愛情点検	長年ご使用のエアロチーノの点検を！	
	こんな症状はありませんか ●電源プラグ・コードが異常に熱くなる。 ●コードに傷が付いたり、通電したりしなかったりする。 ●本体が変形したり、異常に熱い。 ●本体からミルクが漏れる。	ご使用中止 事故防止のため、使用を中止し、コンセントから電源プラグを抜いて必ず下記ネスプレッソクラブにご相談ください。

ネスプレッソクラブ

製品の故障に関するお問合せや、ご使用の際にご不明な点がございましたら、下記ネスプレッソクラブまでお問い合わせください。また、弊社Webサイト内「FAQ/お問合せ」ページでは、電子メールでのお問い合わせも受けつけています。

- フリーダイヤル番号: 0120-57-3101
- フリーダイヤルファックス番号: 0120-37-0837
- Webサイト(PC版): www.nespresso.com
- FAQお問合せページ: 上記Webサイトの「FAQ/お問合せ」をクリック
- Webサイト(モバイル版): http://m.nespresso.com
- ネスプレッソモバイルアプリ: www.nespresso.com/mobile/jp/ja/applications

保証書

この保証書は、本書記載内容で修理を行うことをお約束するものです。お買い上げ日から下記期間中に故障が発生した場合は、ネスプレッソクラブに修理をご依頼ください。

品名	ネスプレッソ牛乳沸かし器		
型名	エアロチーノ 4		
保証期間	お買い上げ日より1年	対象部分	エアロチーノ本体と電源ベース
お買い上げ日	年	月	日
販売店	販売店名・住所・電話番号 お買い上げ店が発行した領収書を貼付・保管してください。		

無料修理規定

- 取扱説明書、本体貼付ラベル等の注意書きに従って正常な状態で故障した場合には、無料修理致します。
- 保証期間内に故障して無料修理をお受けになる場合には、ネスプレッソクラブにご依頼ください。本書の写しをご提示いただく場合があります。
- 保証期間内でも、次の場合には有償修理となります。
 - ① 使用上の誤りによる故障及び損傷
 - ② ネスプレッソの指定工場以外で修理した場合に起きる損傷。
 - ③ 一般家庭以外(例えば、業務用の長時間使用、車輻や船舶への搭載)に使用された場合の故障及び損傷。
 - ④ 取扱説明書に明示された電源条件以外(携帯発電機等)の電源で使用された場合の故障及び損傷。
 - ⑤ 日本国外で使用された場合の故障及び損傷。
 - ⑥ お買い上げ後の輸送、移動、落下による故障及び損傷。
 - ⑦ 自然損耗による故障。

⑧ 火災、地震、水害、落雷、その他の天災地変、公害や異常電圧による故障及び損傷。自然損耗による故障。

⑨ 本書の写しのご提示を求めた際に、ご提示がない場合。

⑩ 本書にお買い上げ年月日、販売店名の記入のない場合、あるいは字句を書き替えられた場合。

- ※ この保証書は再発行いたしませんので、大切に保管してください。
- ※ この保証書は、本書に明示した期間、条件のもとにおいて無料修理をお約束するものです。従ってこの保証書によってお客様の法律上の権利を制限するものではありません。
- ※ 保証期間経過後は、診断をして修理できる場合にはご要望により修理させていただきます。修理料金は次のもので構成されています。
部品代: 部品および補助構成材
技術料: 診断、修理、調整、点検などの費用
配送費: 故障した製品を宅配便でお引取りし、修理後の製品を宅配便でお届けする費用
- ※ 保証期間経過後の修理についてご不明な場合は、ネスプレッソクラブにお問い合わせください。

- ※ 保証期間経過後の修理・補修性能部品の保有期間は、製造中止後5年間です。
- ※ この保証書は日本国内においてのみ有効です。(This warranty is valid only in Japan.)
- ※ 著しい破損や汚損(虫等によるものを含む)、または不当な修理や改造による故障や損傷など、修理ができない場合があります。
- ※ 牛乳沸かし器の修理のご依頼や、ご使用の際のご不明な点がございましたら、ネスプレッソクラブへお問い合わせください。
- ※ 修理の際にお客様からいただいた個人情報は、この保証書において規定された修理その他のサービスのためにのみ使用させていただきます。お客様の承諾なく第三者に開示することはありません。ただし、サービスの全部または一部を第三者に委託する場合は、委託業務に必要な範囲内で、当該第三者に開示することがあります。なお、ネスプレッソクラブにご登録いただいているお客様の個人情報につきましては、別途ネスプレッソクラブにおいて定める範囲で使用させていただきます。

ネスプレッソ 牛乳沸かし器の修理等のお問い合わせ
ネスプレッソクラブ
0120-57-3101(フリーダイヤル) 月曜日～土曜日 9:00～18:00(祝日を除く)
0120-37-0837(フリーダイヤルファックス)

